

Quick Reference Guide Programming Handset Keys

This guide will explain how to change the programming of a key on your phone. Please note when programming the keys on your phone, you will not be able to change line keys.

Adding/Changing a key

- 1. From the phone you wish to change the key on, press the "**Information**" key. This key is found just under your navigation arrows and is a lower case "**i**" surrounded by a circle.
- 2. Once you have done that, select the key you wish to change.
- 3. From there, press the button next to what you wish to change either the name or number.
- 4. To change the name, use the keypad at the bottom of your phone. To change the number, use the dial pad to change the number.
- 5. After you are happy with your changes, press the "**OK**" button.
- 6. To get back to the main menu, press the "C" key once.